



MUSCLEPREP

CONCRETE CLEANER & ETCHING FLUID

MUSCLEGLOSS | 431 STEPHENSON HWY | TROY, MI | 866.258.9500 | MUSCLEGLOSS.COM

DIRECTIONS

1. Thoroughly sweep entire area to be etched, removing all debris, peeling paint, or loose concrete. Spray down entire area with water.
2. Mix one part MusclePrep with 4 parts water.
3. Brush, mop, or flood the MusclePrep solution on the area to be etched, making sure the MusclePrep solution is spread evenly over the entire area. Special care should be taken in treating oil and grease stains on the floors.
4. Spray etched area with water, flushing to sewer or out-of-doors.
5. Etched area should be allowed 24 hours to dry before applying primers or topcoatings.

NOTE: MusclePrep should not be applied to aluminum, chrome, and other decorative metals or trim. Some "stainless steels" are misnamed and can be stained. Check inconspicuous area for staining before applying.

HMIS SYMBOL



CAUTION

PLEASE REFER TO THE MSDS SHEETS FOR MORE DETAILED PRECAUTIONARY MEASURES, HANDLING INSTRUCTIONS AND EMERGENCY PROCEDURES.

Avoid contact. Wear protective clothing and wash thoroughly after using. Avoid inhalation of mists. Use only with adequate ventilation. Do not take internally. Avoid contact with decorative metals, may etch or stain. Overexposure can cause eye, skin, or respiratory irritation. Harmful if swallowed. Do not mix with other chemicals. Doing so can evolve heat or toxic gasses. Keep container closed when not in use. Keep out of reach of children.

FIRST-AID

EYES: Flush with copious amounts of water lifting lids and removing contact lenses to ensure complete irrigation. Get medical attention.

SKIN: Flush with water and then wash with soap and water, launder contaminated clothing before reuse. Get medical attention if irritation persists.

INHALATION: Remove to fresh air and assist breathing if necessary. Get medical attention.

INGESTION: Do not induce vomiting. Give several glasses of water to dilute. Seek medical attention immediately.

CONTAINS

Urea, monohydrochlorida CAS# 506-89.